


CrownNet Setup



This section provides you with procedures guiding you through set up of network connections, software installation, interface configuration, network configuration, printer web page setup, and the CrownNet menus.

CrownNet using Ethernet is built into most QMS printers and Token Ring can be added as an optional interface on QMS printers. The Ethernet port, also referred to as the QMS CrownNet network interface, is a combination of hardware and host software that allows you to connect your QMS printer to an Ethernet network that supports:

- Apple Talk through EtherTalk protocol
- LAN Manager/LAN Server through NetBIOS/NetBEUI protocol
- NetWare through IPX/SPX protocol
- TCP/IP through TCP/IP protocol
- Windows 3.1/Windows 95/Windows NT through TCP/IP, netBIOS/NetBEUI, EtherTalk protocols

CrownAdmin utilities software enables you to configure your printer through any of these environments and protocols.